DEM-LINE – Special Functi ons Cards and Keyfobs
Manage Keys and Features of your DEM-Family through reader batchpoint.

ACCESS CARD	**Access Card / Keyfob** And open show cases that are secured with a MEMO electronic Locking & Security system as soon as they are programmed (authorized). At delivery, these keys are neutral and must be programmed following the described procedure in this document. Lost or stolen Chip Keys must be reported to the management immediately to avoid possible misuse! **Access Cards or Fobs OPEN doors!**
MASTER CARD 1	**Master Card / System Card** Identify the system owner, and they are required for any administrative operation such as setting changes or key programming. **Master Cards NEVER OPEN doors!**
PROGRAMMING	**Programming Card / Keyfob** Is used for convenient programming of Access Key Fobs via reader. **Programming Cards NEVER OPEN doors!**
ERASE CARD	**Erase Card** Is used to erase ALL KEYS in one go conveniently through the reader. Using this card will erase ALL ACCESS KEYS! Keys must be programmed again to resume normal operation! **Erasing Card NEVER OPEN doors!**
DECORATION	**Decoration Card / Keyfob** allows for convenient show case decoration without warning sounds and door open limitations. We recommend use this card only outside normal shop opening times! Access should be granted only to authorized decoration – staff. **Decoration Cards OPEN doors!**
SUPERVISOR	**Supervisor Card / Keyfob** Are used by the shop supervisor to stop Intrusion Alarms. **Supervisor Cards NEVER OPEN doors!**