


Cables - AIR2-LINE

Lock Cables


Extension Cable 3 m for magnetic Lock AIR2-LINE MI-CAB1-5001-03AIR

Extend the cable from an AIR2-line LOCK to the CONTROLLER with this cable by 3 meters, maximum total cable length 12m.




Lock Cable 3m for 3rd party magnetic Lock AIR2-LINE MI-CAB1-5000-03AIR

Connect any electric lock with 12V operating voltage / max 1A current consumption by using this cable, clip connector connect the lock with power, open cable ends connect to a door sensor.




Device Cable for 3rd party, switching contact signal AIR2-LINE MI-CAB1-5010-03AIR

Use this cable to switch any electric device with max 1A current consumption / max 48V by using this cable, clip connector connect the device with switching signal, open cable ends connect to a door sensor.




Dual lock Adapter Cable 20cmAdaptor cable 15cm DEM->AIR MI-CAB0-0002-L0AIR

Use this cable when a show case is locked with 2 locks in parallel – ONLY ONE lock requires this adapter cable while the other lock will be connected directly to the same controller.




Adapter Cable 15cm DEM>AIR for locks and LTU from AIR>DEM MI-CAB0-AIR-DEM

Use this cable to connect any lock type from MEMOs AIR2-LINE products with any diamond-e-motion controller.




Adapter Cable 15cm DEM>AIR for lock 2600/2700 MI-CAB0-DEM-AIR*2600

Use this cable to connect a lock type 2600/2700 from MEMOs DIAMOND-E-MOTION product line with any AIR2 controller.



Adapter Cable 15cm DEM>AIR for locks MI-CAB0-DEM-AIR*LOCK

Use this cable to connect any lock type from MEMOs DIAMOND-E-MOTION product line with any AIR2 controller.




Cables - AIR2-LINE

Readers Cables

Reader Extension Cable 3m AIR2-LINE

MI-CAB3-0001-03AIR


Extend the cable length from an AIR2-line READER to the CONTROLLER with this cable by 3 meters, maximum total cable length 12m.



Reader Extension Cable 6m AIR2-LINE

MI-CAB3-0001-06AIR



Extend the cable length from an AIR2-line READER to the CONTROLLER with this cable by 6 meters, maximum total cable length 12m.



Adaptor Reader Cable 15cm DEM->AIR

MI-CAB3-DEM-AIR

Use this cable to adapt the connection between an DEM reader and a AIR controller, with a fixed cable length of 15 cm.



Adaptor Reader Cable 15cm AIR->DEM

MI-CAB3-AIR-DEM

Use this cable to adapt the connection between an AIR reader and a DEM controller, with a fixed cable length of 15 cm.

