



MEMO LOCK APP

How to activate Watchmaker Mode - User Guide



HOW TO ACTIVATE WATCHMAKER MODE

Quick and Easy Step-by-Step




Video Tutorial



ATTENTION:

When an authorized access key is presented to the reading batch point, the lock is unlocked.



At the next presentation of an authorized access key, the lock closes and remains locked



Open the app.


In the bottom menu, select “Features”.

On the displayed screen, locate the Opening Modes list.





Tap v to open “Watchmaker Mode” feature details.


Enable the switch to activate the feature.




A confirmation message will appear automatically.




Present an authorized access key to the reader batch point to open the door.




After presentation, The lock will remain in an open position indefinitely.




Open the showcase



If you Close the door, the door will remain open since the Lock is still in an open position.




To securely close the door, present an authorized access key again.



This will trigger the system to change the lock to a closed position.

CORRECT DOOR CLOSING. Perform a push and pull test on the door to ensure it's full locked.



1. PUSH INSIDE to CLOSE

2. PULL OUTSIDE to CHECK

3. PUSH INSIDE to REMOVE TENSION

Perform this PUSH-PULL-PUSH closing EVERY time you close a door and drawer!

CONCLUSION

By following this guide, you will be able to **SET UP** your system consisting of **MEMO AIR2-LINE** and **DEM EVO3** devices using **MEMO LOCK APP**. For additional support, contact the MEMO team via the official website or the technical support information provided in the product materials.

Thank you for choosing the most versatile and powerful security system.