



# MEMO LOCK APP

How to Activate Opening Delay - User Guide



# HOW TO ACTIVATE OPENING DELAY

Quick and Easy Step-by-Step



Video Tutorial

**ATTENTION:**


- This is a paid feature, valid for 1 month per controller.
- There is a 3 month trial period available to test out all security features
- You can purchase the feature on our website by clicking Purchase Feature.




**IMPORTANT:**

- This feature introduces a predefined delay for a door to open after an authorized Access Key is presented.
- The door will unlock only after the countdown completes.
- This delay helps prevent rapid break-in attempts, making it highly effective for securing high-value items in display cases.


Copyright © 2025 MEMO International Ltd., F-17 Mosta Technopark, Mosta 3000, MALTA  
www.memolocks.com, Telephone: +356 21492262, E-mail: support@memo.co.at




Open the app.  
In the bottom menu, select “Features”.




On the displayed screen, locate the Security Features list.




Enable “Opening Delay” feature.  
The default value is 0 seconds.  
Use the minus or plus buttons to increase or decrease the time.





For this example, the opening delay will be set to 10 seconds.



If not purchased, a pop-up will be shown to start the 3-month free trial period.



Once activated, the feature will be enabled, and the remaining time will be displayed at the bottom.  
A confirmation message will appear automatically.




Present an authorized Access Key and open the showcase.




Wait for the predefined opening delay time to pass.



A specific 2 beep sound will be heard and the door will unlock automatically and can be opened.





Open the showcase door.





After use, close the door securely.



**CORRECT DOOR CLOSING.** Perform a push and pull test on the door to ensure it's full locked.



1. PUSH INSIDE to CLOSE



2. PULL OUTSIDE to CHECK



3. PUSH INSIDE to REMOVE TENSION

**Perform this PUSH-PULL-PUSH closing EVERY time you close a door and drawer!**

## CONCLUSION

By following this guide, you will be able to **SET UP** your system consisting of **MEMO AIR2-LINE** and **DEM EVO3** devices using **MEMO LOCK APP**. For additional support, contact the MEMO team via the official website or the technical support information provided in the product materials.

Thank you for choosing the most versatile and powerful security system.